



# SNS COLLEGE OF TECHNOLOGY

Coimbatore – 35

An Autonomous Institution

Accredited by NBA – AICTE and Accredited by NAAC – UGC with 'A++' Grade

Approved by AICTE, New Delhi & Affiliated to Anna University, Chennai



## DEPARTMENT OF ELECTRONICS AND COMMUNICATION ENGINEERING

19ECT311 / Wireless Communication

III ECE/ VI SEMESTER

Unit I -**FUNDAMENTALS OF WIRELESS COMMUNICATION**

**Topic 6 : Interference and system capacity**



# Interference and System Capacity

- It is a major limiting factor in the performance of cellular radio systems.
- Creates bottleneck in increasing capacity
- Interference in Voice Channels: Cross-Talk
- Interference in Control Channels: missed/blocked calls
- Urban areas usually have more interference, because of:
  - a) Greater RF Noise Floor,
  - b) More Number of Mobiles



# Interference and System Capacity

- Sources of interference
  - Another mobile in the same cell
  - A call in progress in the neighboring cell
  - Other base stations operating in the same frequency band
  - Noncellular system leaks energy into the cellular frequency band
- Two major cellular interference
  - Co-channel interference
  - Adjacent channel interference



# Co-channel Interference and System Capacity



- Frequency reuse - there are several cells that use the same set of frequencies
- The cells that use the same set of frequencies are called co-channel cells
- The interference between signals from these cells is called Co-Channel Interference (CCI)
- Cannot be controlled by increasing RF power. Rather, this will increase CCI
- To reduce co-channel interference, co-channel cell must be separated by a minimum distance



# Co-channel Interference and System Capacity




- When the size of the cell is approximately the same
  - co-channel interference is independent of the transmitted power
  - co-channel interference is a function of
    - $R$ : Radius of the cell
    - $D$ : distance to the center of the nearest co-channel cell
- Increasing the ratio  $Q=D/R$ , the interference is reduced
- $Q$  is called the co-channel reuse ratio



# Co-channel Interference and System Capacity

- ❑ The yellow cells use the same set of frequency channels, and hence, interfere with each other
- ❑ In the cellular system there are 6 first-layer co-channels





# Co-channel Interference and System Capacity



- For a hexagonal geometry

$$Q = \frac{D}{R} = \sqrt{3N}$$

- A small value of  $Q$  provides large capacity
- A large value of  $Q$  improves the transmission quality - smaller level of co-channel interference
- A tradeoff must be made between these two objectives

**Co-channel Reuse Ratio for Some Values of  $N$**

|                | Cluster Size ( $N$ ) | Co-channel Reuse Ratio( $Q$ ) |
|----------------|----------------------|-------------------------------|
| $i = 1, j = 1$ | 3                    | 3                             |
| $i = 1, j = 2$ | 7                    | 4.58                          |
| $i = 2, j = 2$ | 12                   | 6                             |
| $i = 1, j = 3$ | 13                   | 6.24                          |



# Co-channel Interference



- Let  $i_0$  be the number of co-channel interfering cells.
- The signal-to-interference ratio (SIR) for a mobile receiver can be expressed as

$$\frac{S}{I} = \frac{S}{\sum_{i=1}^{i_0} I_i}$$

$S$  : the desired signal power

$I_i$  : interference power caused by the  $i$ th interfering co-channel cell base station

- $n$  is the path loss exponent which ranges between 2 and 4



# Co-channel Interference




- The average received power at a distance  $d$  from the transmitting antenna is approximated by

$$P_r = P_0 \left( \frac{d}{d_0} \right)^{-n}$$

or

$$P_r(\text{dBm}) = P_0(\text{dBm}) - 10n \log \left( \frac{d}{d_0} \right)$$





# SIR



- When the transmission power of each base station is equal, SIR for a mobile can be approximated as

$$\frac{S}{I} = \frac{R^{-n}}{\sum_{i=1}^{i_0} (D_i)^{-n}}$$


- Consider only the first layer of interfering cells

$$\frac{S}{I} = \frac{(D/R)^n}{i_0} = \frac{(\sqrt{3N})^n}{i_0}$$



# SIR

- Example: AMPS requires that SIR be greater than 18dB
  - $N$  should be at least 6.49 for  $n=4$ .
  - Minimum cluster size is 7






# Co-channel Interference-Example



- For hexagonal geometry with 7-cell cluster, with the mobile unit being at the cell boundary, the signal-to-interference ratio for the worst case can be approximated as

$$\frac{S}{I} = \frac{R^{-4}}{2(D-R)^{-4} + (D-R/2)^{-4} + (D+R/2)^{-4} + (D+R)^{-4} + D^{-4}}$$





# Activity




Activity : Tangram Puzzle



# Adjacent Channel Interference




- Adjacent channel interference: Interference from adjacent in frequency to the desired signal.
  - Imperfect receiver filters allow nearby frequencies to leak into the passband
  - Performance degrade seriously due to *near-far* effect.





# Adjacent Channel Interference



- Adjacent channel interference can be minimized through careful filtering and *channel assignment*
- Keep the frequency separation between each channel in a given cell as large as possible
- A channel separation greater than six is needed to bring the adjacent channel interference to an acceptable level




# Adjacent Channel Interference



- Problem is severer if the user of adjacent channel is in close proximity → **Near-Far Effect**
- The other transmitter captures the receiver of the subscriber
- Also, when a Mobile Station close to the Base Station transmits on a channel , close to the one being used by a weaker mobile
- The BS faces difficulty in discriminating the desired mobile user from the “bleed over” of the adjacent channel mobile.




# Near-Far Effect: Case 1



- The Mobile receiver is captured by the unintended, unknown transmitter, instead of the desired base station



## Near-Far Effect: Case 2



- *The Base Station faces difficulty in recognizing the actual mobile user, when the adjacent channel bleed over is too high.*



# Minimization of ACI

- (1) Careful Filtering ---- min. leakage or sharp transition***
- (2) Better Channel Assignment Strategy***


- Channels in a cell need not be adjacent: For channels within a cell, Keep frequency separation as large as possible.
- Sequentially assigning cells the successive frequency channels.
- Also, secondary level of interference can be reduced by not assigning adjacent channels to neighboring cells
- For tolerable ACI, we either need to increase the frequency separation or reduce the passband BW



# Power Control for Reducing Interference



- Ensure each mobile transmits the smallest power necessary to maintain a good quality link on the reverse channel
  - long battery life
  - increase SIR
  - solve the near-far problem





# Assessment

1. If a signal to interference ratio of 15db is required for satisfactory forward channel performance of a cellular system, what is the frequency reuse factor and cluster size that should be used for maximum capacity if the path loss exponent is (a)  $n=4$  (b)  $n=3$ ? Assume that there are six co channel cells in the first tier, and all of them are at the same distance from mobile .Use suitable approximations.

