



PIN diode:

- * It is a type of photo detector.
- * It converts light energy into electrical energy.
- * PIN diodes are specially operate in reverse bias condition.
- * PIN diode is very sensitive to light so when light falls on the photodiode it easily converts light into electric current.

Symbol:



Here p^+ \rightarrow heavily doped p-type semiconductor.
 n^+ \rightarrow heavily doped n-type semiconductor.
 i \rightarrow undoped intrinsic semiconductor.
(Highly resistive)

The intrinsic semiconductor is sandwiched
btw p type & n type semiconductors.

Working:

PIN diode is made up of p, i, n regions separated
by a highly resistive intrinsic layer. This is because
intrinsic layer is placed btw p & n because
region to the width of the depletion region.

p & n are heavily doped, therefore, p & n region
of PIN diode has large number of charge carriers to
carry electric current.

Intrinsic \rightarrow undoped \rightarrow It doesn't have charge
carriers to conduct electric current.

under reverse bias condition, majority charge carriers in n type & p type move away from the junction.

As the result, the width of the depletion region becomes very wide.

When light (λ) photon is applied to the PIN diode, the most part of the energy is observed by the intrinsic region because of wide depletion width. As the result, e-h hole pairs are created.

Free electrons generated in the intrinsic region moves towards N side & holes moves towards P side.

Free electrons moves from one region to another region carries electric current.

When forward bias is applied to the PIN diode it behaves as a "resistor".

When reverse bias is applied to the PIN diode it behaves as a "capacitance".

Advantages:

- (i) wide band width
- (ii) high response speed
- (iii) high sensitivity to light
- (iv) low sensitivity to temp.
- (v) low cost
- (vi) small size
- (vii) long lifetime

disadvantage:

- * PIN diode should always operated in reverse bias condition.
- * Reverse bias voltage is low.

Applications:


- * in signal isolators.
- * used as radio frequency switches.
- * used as photo detectors.
- * used as photodetectors in optical fibers.
- * used in medical treatment (MRI).
- * High voltage rectifier.

Avalanche photo diode:

It is the photo detector. It converts light energy into electrical energy.

It operates in reverse bias condition.

Symbol:



It is the four layer device.

p^+ → heavily doped { There are very large no. of charge carriers
 n^+ → heavily doped and its resistivity is low


i → intrinsic layer.

p → lightly doped region.

p^+ acts like anode

n^+ " " cathode.

APD works like photo detector, when it operate in reverse bias condition.



when the light is applied, light enters to p^+ region to i region, the photons are interact with atoms in the intrinsic region.

Because of interaction the e-h or hole pairs are generated in intrinsic region.

In Intrinsic region the e-h or hole pairs experience high electric field because of reverse bias.

Because of this high electric field, the e^- moves toward P region & holes moves towards P+ region.

e^- drifted to P+ region will again experiences very high electric field b/w P & P+ region are accelerated.

e^- s are accelerated due to high EF in P-N junction. They will get sufficient energy to emit secondary e^- s in its path.

These secondary e^- s has sufficient KE to generate one more e^- & hole pairs if it is repeated.

The process of generating more number of e^- & hole pair is called "Impact Ionization".

Because of impact ionisation multiple charge carriers are produced.


only the e^- s will participate in the process of impact ionisation.

Every e^- & hole pair has ability to generate the m no. of e^- & hole pairs.

m → multiplication factor.

$$I_p = q N_e^m \Rightarrow I_p \rightarrow \text{Photo current}$$

q → charge of e^- .



It has high internal gain

Application:

i) high sensitivity (detect light in low intensity)

ii) very high response time.

iii) ability to generate very high current.

iv) they have internal current gain mechanism.

disadvantages

→ It requires high voltages to operate.

→ O/P is not linear.